

Yealink AX83H

User Guide



Call Features

Placing a call

Using the Handset:

1. Pick up the handset
2. Enter the number directly on the dialler and press 

Using the Speakerphone:

1. Enter the number directly on the dialler and press 
2. Then press 

Using the Headset:

1. With the headset connected, enter the number directly on the dialler and press 

Answering a call

Using the Handset:

Pick up the handset.

Using the Speakerphone:

Press 

Using the Headset:

When the phone is connected to a headset, when a call comes in, press the  key to answer call using the headset by default.

Call Hold

To place a call on hold:

Press the Options soft key during a call, and select Hold.

To resume the call, do one of the following:

- If there is only a call on hold, press the **Resume** soft key.
- If there are two calls on hold, press the **Resume** soft key to resume the current call.
- Press the **Swap** soft key to swap between the two calls.

Redial

When the phone is in idle mode press the   to enter the dialling screen.

If the dialling field is blank, press  again to redial the last outgoing number.

Call Transfer

Blind Transfer

1. Press the **TRAN** key during a call
2. Done one of the following:
 - Enter the number or select a contract from the placed call list you want to transfer to.
 - Press **Directory**. Select the desired contact from the **Directory** list.
3. Press **B Transfer** to complete the transfer.

Attended Transfer

1. Press the **TRAN** key during a call.
2. Do one of the following:
 - Enter the number or select a contact from the call list you want to transfer the call.
 - Select **Directory** and select the desired contact from the **Directory** list.
3. Press the **OK** key or 
4. Done one of the following:
 - When you hear the ringback tone, press the **TRAN** key to finish a semi-attended transfer.
 - After the contact answers the call, press the **TRAN** key to finish an attended transfer.

Ending a call

Using the Handset:

Hang up the handset or press 

Using the Speakerphone:

Press 

Using the Headset:

Press 
Or press the **Call Control** button on the Bluetooth headset.

Call Conference

1. Place a call to the first party.
2. Select **Conference** to place a new call.
3. Dial the second party's number.
4. When the second party answers the call, select **Conference** to add the second party to the conference.
5. Repeat the above steps to add more parties to the conference.

Voice Message

Messages waiting indicator on the idle screen indicates that one or more voice messages are waiting at the message centre. The power indicator LED slowly flashes red.

To listen to voice messages:

1. Press the **Message Key**.
2. Follow the voice prompts to listen to your voice messages.

Customising your phone

Call History

1. Press History or go to **Menu > History**.
2. Select the desired list.
3. Select the desired entry.
4. Select **Options > Detail**.

Volume Adjustment

During a call, press the  and  keys to adjust the volume.
In the idle status, press the  and  keys to adjust the volume by default.



Download the Xelion Apps

Scan this QR code to download the latest Xelion Apps (mobile and softphone) direct from their website



Watch a demo

Scan this QR code to see a demo video of this handset